


Please lay out all parts and read instructions prior to assembly





How to assemble your deluxe wrap and craft station



Uncompress the top portion of the storage bag.



Unzip and fully open the storage bag.




Unzip the accessories flap to access the back of the bag.



Insert the support board (Part A) inside the back fabric pocket.



Unzip the mesh pouches to access the back of the bag.





Insert the last support board inside the back fabric pocket just as in step four.